


# SAGE CINEMA LINE 2 QUICK LOOK WIRING GUIDE



**Two pair of speakers wires are needed. One for High-Pass, and one for Low-Pass. You can bring them in to either the top or bottom of the Line 2**

**Then connect the two modules together using small jumpers**

